



EXHAUST MUFFLER 排氣管




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱	Q'TY 用量	NOTE 備註
1	31610-FLO-00	EXHAUST PIPE ASSEMBLY	1	排氣管總成
2	31613-NAF-00	GASKET, EXHAUST PIPE 25.4*34*4	1	排氣管墊片
3	31618-SAF-00	PROTECTOR, MUFFLER	1	消音筒護罩
4	94714-06018-C	SCREW, FLANGE	2	十字孔凸緣螺栓
5	96316-06010-B	SCREW, PAN HEAD	2	十字孔頭螺絲
6	96414-08020-K	BOLT, FLANGE	1	凸緣螺栓
7	96414-08030-K	BOLT, FLANGE	1	凸緣螺栓
8	97210-061215	WASHER, PLATE	4	石棉墊圈

FRAME 車架




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		Q'TY 用量	NOTE 備註
1	41110-FLO-00	FRAME COMP	車架整體	1	OPTION
2	52850-FKO-00	BUMPER REAR	後保護桿	1	
3	53481-FKO-00	PANEL COMP, FLOOR	腳踏板	1	
4	56250-FKO-00	SEAT BELT	安全帶	1	
5	93330-152118	BUSH, SOLID	羅龍滑動軸承	2	
6	93510-101504	COLLAR	軸環	2	
7	95311-081308-B	NUT, NYLON	尼龍螺帽	2	
8	95311-101710-B	NUT, NYLON	尼龍螺帽	3	
9	95401-061006-B	NUT, FLANGE	凸緣螺帽	8	
10	96218-06016-B	BOLT, HEXAGON WITH WASHER	六角螺栓附墊圈	10	
11	96414-10020-B	BOLT, FLANGE	凸緣螺栓	2	
12	96414-10095-B	BOLT, FLANGE	凸緣螺栓	1	
13	96510-08040-B	BOLT, SOCKET 8*40	六角承窩螺栓	2	
14	97201-061820-B	WASHER, PLATE 6*18*2.0	平面墊圈	8	

STEERING 轉向裝置




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱	Q'TY 用量	NOTE 備註
1	42101-FLO-00	COLUMN, STEERING	1	轉向桿
2	42140-FKO-01	ROD, TIE ASS'Y	2	連桿總成
3	42141-FKO-01	ROD, TIE	2	連桿
4	42142-SK9-00	JOINT, UNIVERSAL R	2	萬向接頭 右
5	42143-SK9-00	JOINT, UNIVERSAL L	2	萬向接頭 左
6	42146-RAM-00	NUT	2	連桿螺帽
7	46110-FKO-00	STEERING WHEEL	1	方向盤
8	46411-SK2-00	BEARING, STEERING	2	轉向桿固定座
9	46417-SK2-00	PU BUSH	1	PU襯套
10	62930-SK9-03	HANDLE SWITCH ASS'Y L	1	左把手開關總成
11	90240-23020-B	COTTER PIN 2.3*20	1	開口銷
12	95201-101408-C	NUT, HEXAGON	2	六角螺帽
13	95311-101710-B	NUT, NYLON	4	尼龍螺帽
14	95401-101409-B	NUT, FLANGE	1	凸緣螺帽
15	96218-06016-B	BOLT, HEXAGON WITH WASHER	3	六角螺栓附墊圈
16	96310-05030-G	SCREW, PAN HEAD	1	十字孔頭螺絲
17	96310-05040-G	SCREW, PAN HEAD	1	十字孔頭螺絲
18	96414-08055-B	BOLT, FLANGE	2	凸緣螺栓
19	97201-102620-B	WASHER, PLATE	1	平面墊圈
20	97301-101720-B	WASHER, SPRING 10*17*2.0	1	彈簧墊圈

STEERING KNUCKLE 轉向關節座




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		Q'TY 用量	NOTE 備註
1	45811-SK9-00	PLATE, BRAKE SHOE	前剎車嵌板	2	
2	45815-SK9-00	BRAKE SHOE SET	前剎車塊組	2	
3	45816-SK9-00	SPRING, TENSION	拉伸彈簧	4	
4	45825-SK9-00	COLLAR	轉向關節座軸襯	2	
5	45827-SK9-00	COVER, THRUST	塵封蓋	4	
6	45851-SK9-00	CAMSHAFT	前剎車凸輪軸	2	
7	45855-FLO-00	LEVER, CAMSHAFT	前剎車搖臂	2	
8	45860-FLO-00	KNUCKLE COMP, STEERING L	左前轉向關節座整體	1	
9	45865-FLO-00	KNUCKLE COMP, STEERING R	右前轉向關節座整體	1	
10	93330-172330	BUSH, SOLID	羅龍滑動軸承	4	
11	94340-06010-B	NIPPLE, GREASE	黃油嘴	2	
12	94610-10103-B	BOLT, FLANGE	轉向關節固定軸	2	
13	95311-101710-B	NUT, NYLON	尼龍螺帽	2	
14	96210-05025-B	BOLT, HEXAGON	六角螺栓	2	
15	96510-06012-K	BOLT, SOCKET	六角承窩螺栓	6	

BUMPER 保護桿




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱	Q'TY 用量	NOTE 備註
1	41601-FKO-00	BUMPER, FRONT	1	前保護桿
2	52853-FKO-00	STAY, TAILPLANE	1	尾翼固定座
3	52855-FKO-01	TAILPLANE	1	尾翼
4	53461-FKO-00	STAY , BUMPER SIDE L	1	側保桿固定架左
5	53463-FKO-00	PLATE, SHIELD SIDE	4	側保桿壓板
6	53466-FKO-00	STAY, BUMPER SIDE R	1	側保桿固定架右
7	53471-FKO-00	BUMPER, SIDE	2	側保護桿
8	95401-061006-B	NUT, FLANGE	16	凸緣螺帽
9	96218-06012-B	BOLT, HEXAGON WITH WASHER	10	六角螺栓附墊圈
10	96218-06016-B	BOLT, HEXAGON WITH WASHER	16	六角螺栓附墊圈
11	96414-08012-B	BOLT, FLANGE	2	凸緣螺栓
12	96414-08016-B	BOLT, FLANGE	4	凸緣螺栓

FRONT WHEEL 前輪




NO.	PARTS NO.	PARTS NAME	Q'TY	NOTE
項目	零件號碼	零件名稱	用量	備註
1	42575-SK2-00	TUBE TIRE 15*6-6 JS87	2	內胎
2	42581-SK9-00	HUB, FRONT	2	前輪轂
3	42583-SK2-00	WHEEL, FRONT 1	2	前輪圈1
4	42584-SK2-00	WHEEL, FRONT 2	2	前輪圈2
5	42590-FKO-0002	TIRE, FRONT 15*6-6 K-401Y 4P.R	2	輪胎
6	90240-29025-B	COTTER PIN 2.9*25	2	開口銷
7	93110-20355	OIL SEAL TC 20*35*5	2	油封
8	93110-22406	OIL SEAL TC 22*40*6	2	油封
9	9332C-153511	BALL BEARING 6202 CO	2	滾珠軸承
10	9332C-174012	BALL BEARING 6203 CO	2	滾珠軸承
11	93510-152008-B	COLLAR	2	前輪轂側隔管
12	93510-172209-B	SPACER, BEARING	2	前輪轂隔管
13	94710-10025-C	BOLT, STUD	8	輪圈固定螺栓
14	95321-142215-C	NUT, CASTLE	2	有槽螺帽
15	95401-101409-C	NUT, FLANGE	8	凸緣螺帽
16	96510-06012-K	BOLT, SOCKET	8	六角承窩螺栓
17	97201-142820-C	WASHER, PLANE	2	平面墊圈

REAR WHEEL 後輪




NO.	PARTS NO.	PARTS NAME		Q'TY	NOTE
項目	零件號碼	零件名稱		用量	備註
1	32320-GOO-00	HUB, REAR BRAKE	後剎車轂	2	
2	42570-RAM-00	VALVE, RIM	氣門嘴	2	
3	42882-IDO-00	WHEEL, REAR 8*5.5	後輪圈	2	
4	42890-FKO-0002	TIRE, REAR 16*6.5-8 K-401Y 4P.R	後輪胎	2	
5	90240-29025-B	COTTER PIN 2.9*25	開口銷	2	
6	94717-10033-B	BOLT, STUD	雙頭螺栓	8	
7	95321-142215-C	NUT, CASTLE	有槽螺帽	2	
8	95401-101409-C	NUT, FLANGE	凸緣螺帽	8	
9	97201-142820-C	WASHER, PLATE 14*28*2.0	平面墊圈	2	

REAR HUB 後輪轂




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱	Q'TY 用量	NOTE 備註
1	32310-GOO-00	PLATE, BRAKE SHOE L	1	左後剎車板
2	32315-GOO-00	PLATE, BRAKE SHOE R	1	右後剎車板
3	32345-NAF-00	BRAKE SHOE KIT	2	後剎車塊組
4	32346-NAF-00	SPRING, TENSION	4	拉伸彈簧
5	32351-GKO-00	CAMSHAFT	2	後剎車凸輪軸
6	32366-GKO-00	STEADY, CABLE L	1	鋼索固定座左
7	32367-GKO-00	STEADY, CABLE R	1	鋼索固定座右
8	42835-GKO-00	AXLE, WHEEL	2	後輪軸
9	42836-FKO-00	HUB, REAR L	1	左後輪轂
10	42837-FKO-00	HUB, REAR R	1	右後輪轂
11	45853-RAM-00	PLATE, INDICATOR	2	前剎車指示器平板
12	45855-RAM-01	LEVER, CAMSHAFT L	1	左前剎車搖臂
13	45856-RAM-01	LEVER, CAMSHAFT R	1	右前剎車搖臂
14	93320-174012UU	BALL BEARING 6203LLUCM/2A	2	滾珠軸承
15	95311-101710-B	NUT,NYLON	2	尼龍螺帽
16	96210-06030-B	BOLT, HEXAGON	2	六角螺栓
17	96214-08020-B	BOLT, HEXAGON WITH WASHER	4	六角螺栓附墊圈
18	96414-08016-B	BOLT, FLANGE	10	凸緣螺栓
19	96414-08020-B	BOLT, FLANGE	2	凸緣螺栓
20	96414-10030-B	BOLT, FLANGE	2	凸緣螺栓

FRONT CARRIER 前架




NO.	PARTS NO.	PARTS NAME		Q'TY	NOTE
項目	零件號碼	零件名稱		用量	備註
1	41606-FLO-00	CARRIER, FRONT	前架	1	
2	56270-CHP-00	MIRROR ASS'Y, BACK	後照鏡組	1	
3	96414-08016-B	BOLT, FLANGE	凸緣螺栓	4	

SIDE COVER 側蓋




NO.	PARTS NO.	PARTS NAME		Q'TY	NOTE
項目	零件號碼	零件名稱		用量	備註
1	41610-FKO-00	BRACKET, FENDER FRONT	擋風板固定座	1	
2	42129-FLO-00	GROMMET, WIRE	配線套環	1	
3	51151-FKO-01	FENDER, FRONT	擋風板	1	
4	51172-FKO-00	SIDE COVER L	左側蓋	1	
5	51173-FKO-00	SIDE COVER R	右側蓋	1	
6	93560-68510	COLLAR	軸環	3	
7	93580-81610	GROMMET	套環	3	
8	96318-06012-B	SCREW, PAN HEAD	十字孔頭螺絲	8	
9	96318-06020-B	SCREW, PAN HEAD	十字孔頭螺絲	3	
10	97321-061825-B	WASHER, FLANGE	凸緣墊圈	8	

SEAT 座墊




NO.	PARTS NO.	PARTS NAME	Q'TY	NOTE
項目	零件號碼	零件名稱	用量	備註
1	52721-GKO-00	SLIDING TRACK L	1	
2	52726-GKO-00	SLIDING TRACK R	1	
3	52730-GKO-00	SINGLE SEAT ASS'Y	1	
4	95201-081207-B	NUT, HEXAGON	8	
5	97201-081823-B	WASHER, PLATE	8	
6	97301-081520-B	WASHER, SPRING	8	

FUEL TANK 油箱




NO.	PARTS NO.	PARTS NAME	Q'TY	NOTE
項目	零件號碼	零件名稱	用量	備註
1	43102-RAM-00	CAP ASS'Y	1	汽油箱蓋總成
2	43103-RAM-00	CAP WASHER	1	油箱蓋墊圈
3	43108-SK5-00	CHECK, VALVE	1	汽油逆止閥
4	43110-FKO-01	FUEL TANK	1	汽油箱
5	43500-RAM-00	FUEL COCK ASS'Y	1	油杯
6	43751-SK2-00	OIL TANK	1	潤滑油箱
7	43771-NAF-01	BODY, CAP	1	潤滑油箱蓋
8	90210-12010	CLIP	2	管夾
9	90310-50050	HOSE 5*8*50	1	通氣管
10	90310-50200	HOSE, FUEL	1	汽油管
11	90310-50390	HOSE 5*8*390	1	通氣管
12	93510-061015-B	COLLAR F	4	油箱隔管 前
13	93580-102416	GROMMET R	4	油箱套環 後
14	96218-06016-B	BOLT, HEXAGON WITH WASHER	2	六角螺栓附墊圈
15	96318-06012-B	SCREW, PAN HEAD	2	十字孔頭螺絲
16	96414-06025-B	BOLT, FLANGE	4	凸緣螺栓
17	97201-062220-B	WASHER, PLATE	4	平面墊圈
18	97210-061315	WASHER, PLATE	2	石棉墊圈

STICK SHIFT 排檔裝置




NO.	PARTS NO.	PARTS NAME	Q'TY	NOTE
項目	零件號碼	零件名稱	用量	備註
1	53211-GKO-00	ROD SHIFT	1	排檔桿
2	53214-GKO-00	HEAD SHIFT	1	排檔頭
3	53215-FKO-00	ARM SHIFT	1	排檔臂
4	53216-GKO-00	PROTECTOR	1	排檔桿護套
5	61920-FKO-00	CABLE SHIFT	1	排檔鋼索
6	90230-12008	COTTER PIN	3	開尾銷
7	95201-101708-B	NUT, HEXAGON	1	六角螺帽
8	95401-081208-B	NUT, FLANGE	1	凸緣螺帽
9	96218-06012-B	BOLT, HEXAGON WITH WASHER	1	六角螺栓附墊圈
10	97201-061415-B	WASHER, PLATE	2	平面墊圈
11	97508-20200-B	SPRING	1	扭轉彈簧

THROTTLE, BRAKE 節流、剎車系統




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱	Q'TY 用量	NOTE 備註
1	53221-FKO-00	PEDAL, THROTTLE	1	節流踏板
2	53261-FKO-00	PEDAL, BRAKE	1	剎車踏板
3	61311-FLO-00	CABLE, BRAKE F	1	剎車鋼索 前
4	61320-FLO-00	CABLE, BRAKE R	2	後剎車鋼索
5	61379-CBW-00	NUT, ADJUST	2	調整螺帽
6	61379-NAF-01	NUT, ADJUST	1	調整螺帽
7	61389-NAF-00	PIN, FIXTURE	3	導線固定塊
8	61389-RAM-00	PIN, FIXTURE	1	導線固定塊
9	61620-FLO-00	CABLE, THROTTLE	1	節流鋼索
10	61820-FLO-00	CABLE, FRONT BRAKE	2	前剎車鋼索
11	61861-MUS-00	CABLE, PAN CONNECTOR	1	剎車線接筒
12	61862-MUS-00	SLIDER, CONNECTOR	1	剎車線接筒滑塊
13	61863-MUS-00	SLIDER, CONNECTOR	1	剎車線接筒滑塊
14	90230-12008	COTTER PIN	6	開尾銷
15	94610-06016-B	PIN, CLEVIS	6	帶頭銷
16	95201-061005-B	NUT, HEXAGON	3	六角螺帽
17	96210-06025-B	BOLT, HEXAGON	3	六角螺栓
18	96218-06012-B	BOLT, HEXAGON WITH WASHER	4	六角螺栓附墊圈
19	97501-12115-B	SPRING COMPRESSION	2	後剎車壓縮彈簧
20	97508-20220-B	SPRING	1	扭轉彈簧
21	97508-22222-B	SPRING	1	扭轉彈簧

HAND BRAKE 手剎車




NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱	Q'TY 用量	NOTE 備註
1	53271-MUS-00	HANDLE, HAND BRAKE	1	手剎車拉柄
2	53272-MUS-00	STEADY, HAND BRAKE	1	手剎車托架
3	53273-MUS-00	POSITIONER, HAND BRAKE	1	手剎車鎖位板
4	53274-MUS-00	BUTTON, HAND BRAKE	1	手剎車釋放鈕
5	53275-MUS-00	ROD, TIE	1	手剎車連桿
6	61341-GLO-00	CABLE, HAND BRAKE UPPER	1	手剎車鋼索上
7	61342-FLO-00	CABLE, HAND BRAKE LOWER	1	手剎車鋼索下
8	61379-CBW-00	NUT, ADJUST	2	調整螺帽
9	61379-NAF-01	NUT, ADJUST	1	調整螺帽
10	61389-NAF-00	PIN, FIXTURE	3	導線固定塊
11	61389-RAM-00	PIN, FIXTURE	1	導線固定塊
12	94610-08012-B	PIN, CLEVIS	1	帶頭銷
13	94610-10012-B	PIN, CLEVIS	1	帶頭銷
14	95201-081207-B	NUT, HEXAGON	2	六角螺帽
15	96414-08020-B	BOLT, FLANGE	2	凸緣螺栓
16	97011-06008-B	CIRCLIP	1	E形扣環
17	97011-08008-B	CIRCLIP	1	E形扣環
18	97201-081823-B	WASHER, PLATE	2	平面墊圈
19	97301-081520-B	WASHER, SPRING	2	彈簧墊圈
20	97501-10045-B	SPRING, COMPRESSION	1	手剎車壓縮彈簧
21	97501-12115-B	SPRING COMPRESSION	2	後剎車壓縮彈簧

SPEEDOMETER 速度錶




NO.	PARTS NO.	PARTS NAME		Q'TY	NOTE
項目	零件號碼	零件名稱		用量	備註
1	55510-GKO-00	SPEEDOMETER ASS'Y	速度錶總成	1	
2	55516-BL9-00	HOLDER, SPEEDOMETER	速度錶固定座	1	
3	55517-CBW-00	BULB, WEDGE BASE (12V/1.2W)	燈泡	5	
4	55552-CBW-00	FAR LIGHT LENS	遠燈透鏡	1	
5	55553-CBW-00	FLASHER LENS	方向燈透鏡	2	
6	55556-FLO-00	WIRE, GUIDING LIGHTS	指示燈配線	1	
7	55557-FLO-00	HAND BRAKE LENS	手剎車燈透鏡	1	
8	61520-FLO-01	CABLE, SPEEDOMETER ASS'Y	速度錶鋼索總成	1	
9	95401-050805-B	NUT, FLANGE	凸緣螺帽	2	
10	97201-051610-B	WASHER, PLATE 5.3*16*1	平面墊圈	2	

HEADLIGHT 前燈




NO.	PARTS NO.	PARTS NAME		Q'TY	NOTE
項目	零件號碼	零件名稱		用量	備註
1	55213-BL9-01	PROTECTOR UPPER, HEADLIGHT	前燈上蓋	1	
2	55215-BL9-01	PROTECTOR LOWER, HEADLIGHT	前燈下蓋	1	
3	55300-BLU-01	HEAD LIGHT ASS'Y	前燈總成	1	
4	55314-NFF-00	BULB, HEAD LIGHT 12V 35/35W	前燈燈泡	1	
5	55316-NGF-00	BULB, POSITION LAMP 12V 5W	位置燈燈泡	1	
6	55320-BLU-01	LENS ASS'Y	前燈單元總成	1	
7	55340-BLU-01	SOCKET CORD ASSEMBLY	燈座總成	1	
8	95706-081605-C	NUT, SQUARE	方形定位螺帽	2	
9	96112-51616-K	SCREW, TAPPING	自攻螺絲	3	
10	96414-08012-B	BOLT, FLANGE	凸緣螺栓	2	

FLASHER 方向燈



NO.	PARTS NO.	PARTS NAME	Q'TY	NOTE
項目	零件號碼	零件名稱	用量	備註
1	55350-PAF-00	WINKER ASS'Y, L FRONT	2	前方向燈組左
2	55360-PAF-00	WINKER ASS'Y, R FRONT	2	前方向燈組右
3	55722-SAF-00	REFLECTOR	2	反射片
4	55736-FLO-00	LOCK, WINKER	2	後方向燈固定座
5	95401-061006-B	NUT, FLANGE	2	凸緣螺帽
6	96218-06012-B	BOLT, HEXAGON WITH WASHER	2	六角螺栓附墊圈
7	96612-05012-B	BOLT, HEXAGON WITH WASHER	4	六角十字穴螺栓附墊圈
8	97301-061215-B	WASHER, SPRING	2	彈簧墊圈

TAIL LIGHT 後燈



NO. 項目	PARTS NO. 零件號碼	PARTS NAME 零件名稱		Q'TY 用量	NOTE 備註
1	55700-GKO-00	TAIL LIGHT ASS'Y	後燈總成	1	
2	55713-BL9-00	BULB STAND, TAIL LIGHT	後剎車燈泡座	1	
3	55714-PAF-00	BULB, TAIL LIGHT (12V21/5W)	後剎車燈泡	1	
4	55721-BL9-00	LENS, TAIL LIGHT	後燈罩	1	
5	55726-FLO-00	HOLDER, TAIL LIGHT	後燈固定座	1	
6	55743-BL9-00	LENS, LICENSE LIGHT	牌照燈罩	1	
7	93510-061010	COLLAR	牌照板軸環	2	
8	93580-102212	GROMMET	牌照板套環	2	
9	95401-061006-B	NUT, FLANGE	凸緣螺帽	2	
10	96110-40618-C	SCREW, TAPPING	自攻螺絲	2	
11	96110-41618-B	SCREW, TAPPING	自攻螺絲	2	
12	96218-06012-B	BOLT, HEXAGON WITH WASHER	六角螺栓附墊圈	2	
13	97201-061820-B	WASHER, PLATE	平面墊圈	2	

WIRE HARNESS 主電路配線					
NO.	PARTS NO.	PARTS NAME		Q'TY	NOTE
項目	零件號碼	零件名稱		用量	備註
1	56190-RAM-00	GAUGE, AIR	胎壓計	1	
2	61120-FLO-01	WIRE, HARNESS	主配線總成	1	
3	61135-NAF-00	BAND, CORD 3.7*200L	束帶	4	
4	61135-SK2-00	BAND, CORD 2.5*100L	束帶	4	
5	61151-NAF-00	FUSE	保險絲	1	
6	62100-NAN-00	BATTERY ASS'Y (YTX5L-BS)	蓄電池總成	1	
	62100-NAN-01	BATTERY ASS'Y (GTX5L-BS)	蓄電池總成	1	
7	62112-CHP-00	BAND, BATTERY	電瓶束套	1	
8	62310-NAF-00	IGNITION COIL ASS'Y	點火線圈總成	1	
9	62320-NAF-00	PLUG CAP ASS'Y	火星塞蓋總成	1	
10	62322-NAF-00	SEAL, PLUG CAP	火星塞蓋套	1	
11	62350-NAF-01	FLASHER RELAY ASS'Y	方向警報斷續器總成	1	
12	62360-NAF-00	RECTIFIER & REGULATOR COMP	整流穩壓器	1	
13	62370-NAF-00	HORN	喇叭	1	
14	62500-SK9-00	KEY SET	鎖組	1	
15	62501-SK9-00	MAIN SWITCH ASS'Y	主開關總成	1	
16	62503-RAM-00	LOCK COMP, STEERING HANDLE	轉向舵鎖	1	
17	62540-NAF-00	C.D.I UNIT ASS'Y	C.D.I組件總成	1	
18	62550-SK2-00	STARTER RELAY SWITCH COMP	起動開關組	1	
19	62580-MUS-00	SWITCH ASS'Y, HAND BRAKE LAMP	手剎車燈開關	1	
20	62946-GKO-00	SWITCH UNIT, STARTER	起動按鈕	1	
21	62980-CHP-00	SWITCH ASS'Y, REAR STOP	剎車燈後置開關	1	

2004.11.02

61120-FLO-01A

WIRE HARNESS 主電路配線					
NO.	PARTS NO.	PARTS NAME		Q'TY	NOTE
項目	零件號碼	零件名稱		用量	備註
22	96310-05012-B	SCREW, PAN HEAD 5*12	十字孔頭螺絲	2	
23	96312-06020-C	SCREW, PAN HEAD WITH WASHER	十字孔頭螺絲附墊圈	3	
24	96414-06010-C	BOLT, FLANGE	凸緣螺栓	1	
25	96613-05012-B	BOLT, HEXAGON WITH WASHER	六角十字穴螺栓附墊圈	2	
26	97506-12080-B	SPRING, TENSION	剎車開關拉伸彈簧	1	

2004.11.02

61120-FLO-01A