



# CYLINDER 汽缸




| NO.<br>項目 | PARTS NO.<br>零件號碼 | PARTS NAME<br>零件名稱       | Q'TY<br>用量 | NOTE<br>備註 |
|-----------|-------------------|--------------------------|------------|------------|
| 1         | 11111-NAO-01      | CYLINDER                 | 1          | 汽缸         |
| 2         | 11121-NAO-00      | HEAD, CYLINDER           | 1          | 汽缸蓋        |
| 3         | 11151-NAN-00      | GASKET, CYLINDER         | 1          | 汽缸墊片       |
| 4         | 11181-NAN-00      | GASKET, CYLINDER HEAD    | 1          | 汽缸蓋墊片      |
| 5         | 62210-NAF-01      | PLUG, SPARK (NGK BPR7HS) | 1          | 火星塞總成      |
| 6         | 94717-07124-C     | BOLT, STUD               | 4          | 雙頭螺栓       |
| 7         | 95401-071007-C    | NUT, FLANGE              | 4          | 凸緣螺帽       |

## CRANKSHAFT, PISTON 曲軸、活塞




| NO. | PARTS NO.      | PARTS NAME             |        | Q'TY | NOTE |
|-----|----------------|------------------------|--------|------|------|
| 項目  | 零件號碼           | 零件名稱                   |        | 用量   | 備註   |
| 1   | 11400-SKO-00   | CRANKSHAFT ASSEMBLY    | 曲軸總成   | 1    |      |
| 2   | 11412-SKO-00   | CRANK L                | 左曲軸    | 1    |      |
| 3   | 11422-SKO-00   | CRANK R                | 右曲軸    | 1    |      |
| 4   | 11451-NAN-00   | ROD, CONNECTING        | 連桿     | 1    |      |
| 5   | 11481-NAN-00   | PIN, CRANK             | 曲軸銷    | 1    |      |
| 6   | 11631-NAO-00   | PISTON (STD)           | 活塞     | 1    |      |
| 7   | 11636-NAO-00   | PISTON RING SET (STD)  | 活塞環組   | 1    |      |
| 8   | 93110-20306    | OIL SEAL               | 油封     | 1    |      |
| 9   | 93110-20428    | OIL SEAL               | 油封     | 1    |      |
| 10  | 93310-1215164  | NEEDLE BEARING         | 滾針軸承   | 1    |      |
| 11  | 93310-1824118  | NEEDLE BEARING         | 滾針軸承   | 1    |      |
| 12  | 93320-204714J3 | BALL BEARING 6204JR2C3 | 滾珠軸承   | 2    |      |
| 13  | 93510-081240   | PIN, PISTON            | 活塞銷    | 1    |      |
| 14  | 93510-162115   | COLLAR                 | 左曲軸隔環  | 1    |      |
| 15  | 94420-03013    | KEY, SEMICIRCLE        | 半圓鍵    | 1    |      |
| 16  | 97050-10014    | CIRCLIP                | 活塞銷止動環 | 2    |      |

AIR SHROUD, FAN 空氣進氣孔、風扇




| NO.<br>項目 | PARTS NO.<br>零件號碼 | PARTS NAME<br>零件名稱          | Q'TY<br>用量 | NOTE<br>備註 |
|-----------|-------------------|-----------------------------|------------|------------|
| 1         | 12611-NAN-00      | FAN                         | 1          | 風扇         |
| 2         | 12631-NAF-00      | DEFLECTOR                   | 1          | 轉折板        |
| 3         | 12651-NAN-00      | AIR SHROUD, CYLINDER        | 1          | 汽缸護罩       |
| 4         | 12653-NAF-00      | AIR SHROUD, FAN             | 1          | 風扇護蓋       |
| 5         | 12658-NAF-00      | DAMPER, AIR SHROUD          | 3          | 風扇護蓋防震墊    |
| 6         | 93560-68510       | COLLAR                      | 2          | 軸環         |
| 7         | 93580-41810       | GROMMET                     | 2          | 汽缸護罩套環     |
| 8         | 93580-81610       | GROMMET                     | 2          | 套環         |
| 9         | 96110-64016-C     | SCREW, TAPPING              | 1          | 自攻螺絲       |
| 10        | 96312-06020-K     | SCREW, PAN HEAD WITH WASHER | 2          | 十字孔頭螺絲附墊圈  |
| 11        | 96314-06016-C     | SCREW, PAN HEAD WITH WASHER | 4          | 十字孔頭螺絲附墊圈  |

# OIL PUMP 潤滑油泵




| NO. | PARTS NO.     | PARTS NAME            |        | Q'TY | NOTE |
|-----|---------------|-----------------------|--------|------|------|
| 項目  | 零件號碼          | 零件名稱                  |        | 用量   | 備註   |
| 1   | 13100-GKO-00  | OIL PUMP ASSEMBLY     | 潤滑油泵總成 | 1    |      |
| 2   | 13124-NAF-00  | GEAR WORM WHEEL (40T) | 蝸輪     | 1    |      |
| 3   | 13178-NAF-00  | GEAR, PUMP DRIVE      | 驅動齒輪   | 1    |      |
| 4   | 13185-NAF-00  | BOLT, BREATHER        | 螺栓     | 1    |      |
| 5   | 13187-NAF-00  | GASKET, BREATHER BOLT | 墊圈     | 1    |      |
| 6   | 90210-06005-C | CLIP                  | 管夾     | 1    |      |
| 7   | 90210-08009-C | CLIP                  | 管夾     | 2    |      |
| 8   | 90310-20050   | HOSE                  | 耐油管    | 1    |      |
| 9   | 90310-50430   | HOSE                  | 耐油管    | 1    |      |
| 10  | 93210-16195   | O-RING                | 護油圈    | 1    |      |
| 11  | 94430-30012   | PIN, DOWEL            | 彈簧銷    | 1    |      |
| 12  | 94510-30012   | PIN, POWEL            | 滾針     | 1    |      |
| 13  | 96310-05014-C | SCREW, PAN HEAD       | 十字孔頭螺絲 | 2    |      |
| 14  | 97010-19012   | CIRCLIP               | C形扣環   | 2    |      |
| 15  | 97011-07008-K | CIRCLIP               | E形扣環   | 1    |      |

# CARBURETOR 化油器




| NO.<br>項目 | PARTS NO.<br>零件號碼 | PARTS NAME<br>零件名稱          |           | Q'TY<br>用量 | NOTE<br>備註 |
|-----------|-------------------|-----------------------------|-----------|------------|------------|
| 1         | 13201-NAN-01      | CARBURETOR ASSEMBLY         | 化油器總成     | 1          |            |
| 2         | 13203-NAF-00      | THROTTLE SCREW SET          | 節流調整螺絲組   | 1          |            |
| 3         | 13204-NAF-00      | AIR SCREW SET               | 空氣螺絲組     | 1          |            |
| 4         | 13207-NAF-00      | NEEDLE VALVE SET            | 油門座油針組    | 1          |            |
| 5         | 13211-NAF-00      | NEEDLE SET                  | 油針組       | 1          |            |
| 6         | 13212-NAF-00      | VALVE, THROTTLE             | 節流閥       | 1          |            |
| 7         | 13233-NAF-00      | SPRING, THROTTLE STOP       | 節流閥彈簧     | 1          |            |
| 8         | 13240-NAN-00      | JET, MAIN (#82.5)           | 主噴口       | 1          |            |
| 9         | 13241-NAF-00      | NOZZLE, MAIN                | 主噴嘴       | 1          |            |
| 10        | 13242-NCF-00      | JET, PILOT (#20)            | 引導噴口      | 1          |            |
| 11        | 13247-NAF-00      | O-RING                      | 護油圈       | 1          |            |
| 12        | 13261-NAF-00      | NUT, CABLE ADJUSTING        | 螺帽        | 1          |            |
| 13        | 13271-NAF-00      | PLUNGER, STARTER            | 起動阻塞總成    | 1          |            |
| 14        | 13286-NAF-00      | PIN, FLOAT                  | 浮筒銷       | 1          |            |
| 15        | 13291-NAF-00      | PLUG, DRAIN                 | 排洩口塞      | 1          |            |
| 16        | 13296-NAF-00      | GASKET                      | 墊片        | 1          |            |
| 17        | 13297-NAF-00      | SEAL                        | 封圈        | 1          |            |
| 18        | 13298-NAF-00      | PIPE                        | 管         | 1          |            |
| 19        | 96310-03006-C     | SCREW, PAN HEAD             | 十字孔頭螺絲    | 1          |            |
| 20        | 96312-04008-C     | SCREW, PAN HEAD WITH WASHER | 十字孔頭螺絲附墊圈 | 2          |            |
| 21        | 96312-04012-C     | SCREW, PAN HEAD WITH WASHER | 十字孔頭螺絲附墊圈 | 2          |            |
| 22        | 96312-04014-C     | SCREW, PAN HEAD WITH WASHER | 十字孔頭螺絲附墊圈 | 4          |            |

# INTAKE 空氣吸入口




| NO.<br>項目 | PARTS NO.<br>零件號碼 | PARTS NAME<br>零件名稱          |           | Q'TY<br>用量 | NOTE<br>備註 |
|-----------|-------------------|-----------------------------|-----------|------------|------------|
| 1         | 13410-NAF-00      | AIR CLEANER ASSEMBLY        | 空氣濾清器總成   | 1          |            |
| 2         | 13411-NAF-01      | CASE, AIR CLEANER           | 空氣濾清器箱    | 1          |            |
| 3         | 13412-NAF-00      | CAP, CLEANER CASE           | 空氣濾清器箱蓋   | 1          |            |
| 4         | 13437-NAF-00      | DUCT                        | 防塵管       | 1          |            |
| 5         | 13451-NAF-00      | ELEMENT, AIR CLEANER        | 空氣濾清網     | 1          |            |
| 6         | 13452-NAF-00      | SEAL                        | 濾清箱封圈     | 1          |            |
| 7         | 13453-NAF-00      | JOINT, AIR CLEANER          | 濾清箱接頭     | 1          |            |
| 8         | 13555-NAF-00      | MANIFOLD, INTAKE            | 進氣歧管      | 1          |            |
| 9         | 13610-NAF-00      | REED VALVE ASSEMBLY         | 簧片閥總成     | 1          |            |
| 10        | 13621-NAF-00      | GASKET, VALVE SEAT          | 閥座墊片      | 1          |            |
| 11        | 90210-23043       | CLIP                        | 管夾        | 1          |            |
| 12        | 90260-13325       | CLAMP, HOSE                 | 軟管夾       | 1          |            |
| 13        | 93560-68510       | COLLAR                      | 軸環        | 2          |            |
| 14        | 93580-81610       | GROMMET                     | 套環        | 2          |            |
| 15        | 96110-52512-K     | SCREW, TAPPING              | 自攻螺絲      | 3          |            |
| 16        | 96312-06020-K     | SCREW, PAN HEAD WITH WASHER | 十字孔頭螺絲附墊圈 | 2          |            |
| 17        | 96510-06020-G     | BOLT, SOCKET                | 六角承窩螺栓    | 4          |            |

| CRANKCASE 曲軸箱                                                                     |               |                        |         |     |      |
|-----------------------------------------------------------------------------------|---------------|------------------------|---------|-----|------|
|  |               |                        |         |     |      |
| NO.                                                                               | PARTS NO.     | PARTS NAME             |         | QTY | NOTE |
| 項目                                                                                | 零件號碼          | 零件名稱                   |         | 用量  | 備註   |
| 1                                                                                 | 15111-GOO-00  | CRANKCASE, LEFT        | 左曲軸箱    | 1   |      |
| 2                                                                                 | 15163-NAF-00  | PLUG, OIL              | 油標塞     | 1   |      |
| 3                                                                                 | 15171-NAF-00  | BREATHER               | 通風管接頭   | 1   |      |
| 4                                                                                 | 15211-SK9-00  | CRANKCASE, RIGHT       | 右曲軸箱    | 1   |      |
| 5                                                                                 | 15221-NAF-01  | GASKET, STATOR         | 電盤墊片    | 1   |      |
| 6                                                                                 | 15228-NAF-00  | HOLDER                 | 油封固定座   | 1   |      |
| 7                                                                                 | 15311-GOO-00  | COVER, GEARBOX         | 變速箱蓋    | 1   |      |
| 8                                                                                 | 15351-GOO-00  | GASKET, GEARBOX COVER  | 變速箱蓋墊片  | 1   |      |
| 9                                                                                 | 15411-GOO-00  | COVER, CRANKCASE       | 機箱蓋     | 1   |      |
| 10                                                                                | 15432-GOO-00  | GUIDE, ELEMENT         | 濾網導件    | 1   |      |
| 11                                                                                | 15436-GOO-00  | ELEMENT                | 曲軸箱濾清網  | 1   |      |
| 12                                                                                | 24201-GOO-00  | HOLDER, GEAR CABLE     | 排檔鋼索固定座 | 1   |      |
| 13                                                                                | 42563-GOO-00  | GEAR, SPEEDOMETER BODY | 速度表齒輪本體 | 1   |      |
| 14                                                                                | 45838-GOO-00  | GEAR, SPEEDOMETER 13T  | 速度表齒輪   | 1   |      |
| 15                                                                                | 90311-50070   | HOSE, BREATHER         | 透明管     | 1   |      |
| 16                                                                                | 93110-06114   | OIL SEAL VC 6*11*4     | 油封      | 1   |      |
| 17                                                                                | 93210-19178   | O-RING 1.9*17.8        | 護油圈     | 1   |      |
| 18                                                                                | 93210-24140   | O-RING 2.4*14          | 護油圈     | 1   |      |
| 19                                                                                | 94410-08014   | PIN, DOWEL             | 定位銷     | 2   |      |
| 20                                                                                | 94410-12016   | PIN, DOWEL             | 定位銷     | 2   |      |
| 21                                                                                | 94510-30018   | PIN, DOWEL 3*17.8      | 滾針      | 1   |      |
| 22                                                                                | 96110-41218-K | SCREW, TAPPING         | 自攻螺絲    | 3   |      |

2004.05.18


15111-GOO-01A

| CRANKCASE 曲軸箱                                                                       |                |                 |        |     |      |
|-------------------------------------------------------------------------------------|----------------|-----------------|--------|-----|------|
|  |                |                 |        |     |      |
| NO.                                                                                 | PARTS NO.      | PARTS NAME      |        | QTY | NOTE |
| 項目                                                                                  | 零件號碼           | 零件名稱            |        | 用量  | 備註   |
| 23                                                                                  | 96310-06012-C  | SCREW, PAN HEAD | 十字孔頭螺絲 | 1   |      |
| 24                                                                                  | 96310-06025-B  | SCREW, PAN HEAD | 十字孔頭螺絲 | 15  |      |
| 25                                                                                  | 96310-06030-B  | SCREW, PAN HEAD | 十字孔頭螺絲 | 4   |      |
| 26                                                                                  | 96310-06035-B  | SCREW, PAN HEAD | 十字孔頭螺絲 | 6   |      |
| 27                                                                                  | 96414-06020-B  | BOLT, FLANGE    | 凸緣螺栓   | 1   |      |
| 28                                                                                  | 96414-06025-B  | BOLT, FLANGE    | 凸緣螺栓   | 1   |      |
| 29                                                                                  | 96414-10016-B  | BOLT, FLANGE    | 凸緣螺栓   | 1   |      |
| 30                                                                                  | 97201-041210-K | WASHER, PLATE   | 平面墊圈   | 3   |      |
| 31                                                                                  | 97230-102016   | WASHER, COPPER  | 銅墊圈    | 1   |      |

2004.08.13


15111-GOO-01A

# STARTER 起動機構



| NO.<br>項目 | PARTS NO.<br>零件號碼 | PARTS NAME<br>零件名稱      | Q'TY<br>用量 | NOTE<br>備註 |
|-----------|-------------------|-------------------------|------------|------------|
| 1         | 23524-NAN-00      | WHEEL, STARTER          | 1          | 起動輪        |
| 2         | 23538-NAF-00      | BOSS, GEAR              | 1          | 齒輪轂        |
| 3         | 23570-NAN-01      | STARTER CLUTCH ASSEMBLY | 1          | 起動離合器總成    |
| 4         | 23576-NAN-00      | STARTER CLUTCH, ROLLER  | 3          | 起動離合器滾珠    |
| 5         | 23578-NAF-00      | STARTER CLUTCH, COVER   | 3          | 起動離合器彈簧套   |
| 6         | 23612-NAN-00      | IDLE GEAR               | 1          | 惰齒輪        |
| 7         | 23632-NAF-00      | PLATE, IDLE GEAR        | 1          | 惰齒輪板       |
| 8         | 23650-NAN-00      | IDLE GEAR ASSEMBLY      | 1          | 惰齒輪總成      |
| 9         | 93310-0812100     | NEEDLE BEARING          | 1          | 滾針軸承       |
| 10        | 93310-5559127     | NEEDLE BEARING          | 1          | 滾針軸承       |
| 11        | 94510-80032       | SHAFT, GEAR             | 1          | 齒輪軸        |
| 12        | 94712-05010-B     | SCREW, FLAT HEAD        | 3          | 十字孔埋頭螺絲    |
| 13        | 96310-06012-C     | SCREW, PAN HEAD         | 2          | 十字孔頭螺絲     |
| 14        | 97201-081620-C    | WASHER, PLATE           | 2          | 平面墊圈       |
| 15        | 97201-557606      | GASKET, STARTER WHEEL   | 1          | 起動輪襯片      |
| 16        | 97501-02021       | STARTER CLUTCH, SPRING  | 3          | 起動離合器彈簧    |

CLUTCH 離合器




| NO. | PARTS NO.      | PARTS NAME                  |          | QTY | NOTE |
|-----|----------------|-----------------------------|----------|-----|------|
| 項目  | 零件號碼           | 零件名稱                        |          | 用量  | 備註   |
| 1   | 25602-NAN-01   | SECONDARY SHEAVE ASSEMBLY   | 副槽輪總成    | 1   |      |
| 2   | 25611-NAF-00   | CLUTCH HOUSING COMP         | 離合器殼整體   | 1   |      |
| 3   | 25620-NAF-00   | CLUTCH CARRIER ASSEMBLY     | 離合器牽轉具總成 | 1   |      |
| 4   | 25626-NAN-01   | SPRING, CLUTCH WEIGHT       | 離合器重量彈簧  | 3   |      |
| 5   | 25660-NAF-00   | SECONDARY FIXED SHEAVE COMP | 副固定槽輪    | 1   |      |
| 6   | 25664-NAF-00   | PIN, GUIDE                  | 導銷       | 2   |      |
| 7   | 25670-NAF-00   | SECONDARY SLIDING SHEAVE    | 副滑動槽輪    | 1   |      |
| 8   | 25680-NAF-01   | SPRING, COMPRESSION         | 壓縮彈簧     | 1   |      |
| 9   | 25684-NAF-00   | SEAT, SECONDARY SPRING      | 副彈簧座     | 1   |      |
| 10  | 25711-NAN-00   | SHEAVE, PRIMARY FIXED       | 主固定槽輪    | 1   |      |
| 11  | 25716-NAN-00   | WASHER, CLAW                | 鉗墊圈      | 1   |      |
| 12  | 25720-NAN-00   | PRIMARY SLIDING SHEAVE COMP | 主滑動槽輪整體  | 1   |      |
| 13  | 25721-NAN-00   | PRIMARY SLIDING SHEAVE      | 主滑動槽輪    | 1   |      |
| 14  | 25723-NAN-00   | CAM, PLATE                  | 凸輪板      | 1   |      |
| 15  | 25732-NAN-03   | WEIGHT ROLLER               | 重錘滾子     | 6   |      |
| 16  | 25741-YAF-03   | V-BELT                      | 皮帶       | 1   |      |
| 17  | 25753-NAF-00   | SLIDER                      | 滑件       | 3   |      |
| 18  | 93110-33394    | OIL SEAL KC 33*39*4         | 油封       | 2   |      |
| 19  | 93210-20360    | O-RING 36*2.0               | 護油圈      | 2   |      |
| 20  | 93510-162137   | BUSHING, SLIDING CLUTCH     | 主滑動槽輪襯套  | 1   |      |
| 21  | 93510-212622   | BUSHING, SLIDING SHEAVE     | 主滑動槽輪銅襯套 | 1   |      |
| 22  | 95201-101708-C | NUT, HEXAGON                | 六角螺帽     | 1   |      |

2004.05.18

25602-NAN-01A

CLUTCH 離合器




| NO. | PARTS NO.      | PARTS NAME             |        | QTY | NOTE |
|-----|----------------|------------------------|--------|-----|------|
| 項目  | 零件號碼           | 零件名稱                   |        | 用量  | 備註   |
| 23  | 95201-102406-C | NUT, HEXAGON           | 六角螺帽   | 1   |      |
| 24  | 95201-284104-C | NUT, HEXAGON           | 六角螺帽   | 1   |      |
| 25  | 97201-162420-B | WASHER, PLATE          | 平面墊圈   | 1   |      |
| 26  | 97310-102425   | WASHER, CONICAL SPRING | 錐形彈簧墊圈 | 1   |      |

2004.05.18

25602-NAN-01A

## TRANSMISSION 傳動機構




| NO. | PARTS NO.     | PARTS NAME                  | QTY | NOTE   |
|-----|---------------|-----------------------------|-----|--------|
| 項目  | 零件號碼          | 零件名稱                        | 用量  | 備註     |
| 1   | 15332-GOO-00  | IDLE GEAR BASE              | 1   | 惰齒輪座   |
| 2   | 24206-GOO-00  | SHIFT LEVER                 | 1   | 變速拉桿   |
| 3   | 24216-GOO-00  | CAM AXLE, GEAR SHIFT        | 1   | 變速凸輪軸  |
| 4   | 24226-GOO-00  | CAM, GEAR SHIFT             | 1   | 齒輪變速凸輪 |
| 5   | 24236-GOO-00  | SHAFT, GEAR SHIFT FORK      | 1   | 變速叉樞軸  |
| 6   | 24238-GOO-00  | FORK, GEAR SHIFT            | 1   | 齒輪變速叉  |
| 7   | 26111-GOO-00  | GEAR, PRIMARY DRIVE 15T/16T | 1   | 主驅動軸   |
| 8   | 26410-GOO-00  | MAIN AXLE COMP              | 1   | 惰輪軸總成  |
| 9   | 26411-GOO-00  | GEAR, IDLE 17T-6T           | 1   | 惰輪軸    |
| 10  | 26412-GOO-00  | GEAR, FORWARD 41T           | 1   | 前進齒輪   |
| 11  | 26413-GOO-00  | WASHER, GEAR                | 1   | 齒輪墊圈   |
| 12  | 26415-GOO-00  | AXLE, IDLE GEAR             | 1   | 倒檔惰齒輪軸 |
| 13  | 26416-GOO-00  | IDLE GEAR, REVERSE 20T      | 1   | 倒檔惰齒輪  |
| 14  | 26426-GOO-00  | GEAR, REVERSE 37T           | 1   | 倒檔齒輪   |
| 15  | 26430-GOO-00  | CLUTCH, DOG                 | 1   | 變檔鼓    |
| 16  | 26440-GOO-00  | GEAR, TRANSMISSION          | 1   | 換檔齒輪   |
| 17  | 93110-10205   | OIL SEAL TC 10*20*5         | 1   | 油封     |
| 18  | 93110-17307   | OIL SEAL TC 17*30*7         | 1   | 油封     |
| 19  | 93320-153511S | BALL BEARING 6202CS05/2A    | 2   | 滾珠軸承   |
| 20  | 93320-1740123 | BALL BEARING 6203C3         | 1   | 滾珠軸承   |
| 21  | 93320-174714M | BALL BEARING 6303CM/2A      | 1   | 滾珠軸承   |
| 22  | 93510-121909  | SPACER, IDLE GEAR           | 1   | 惰齒輪隔管  |

2004.05.18

26111-GOO-00A

## TRANSMISSION 傳動機構




| NO. | PARTS NO.      | PARTS NAME          | QTY | NOTE   |
|-----|----------------|---------------------|-----|--------|
| 項目  | 零件號碼           | 零件名稱                | 用量  | 備註     |
| 23  | 94430-30018-K  | PIN, DOWEL          | 2   | 彈簧銷    |
| 24  | 94510-45045    | PIN, DOWEL 4.5*44.7 | 1   | 平行銷    |
| 25  | 94520-06350    | BALL                | 1   | 鋼珠     |
| 26  | 95201-081406-B | NUT, HEXAGON        | 2   | 六角螺帽   |
| 27  | 96414-08016-B  | BOLT, FLANGE        | 1   | 凸緣螺栓   |
| 28  | 96414-08050-B  | BOLT, FLANGE        | 2   | 凸緣螺栓   |
| 29  | 97012-20012    | CIRCLIP             | 1   | C形同心扣環 |
| 30  | 97231-081620   | WASHER, ALUMINUM    | 1   | 鋁墊圈    |
| 31  | 97501-10034    | SPRING, COMPRESSION | 1   | 壓縮彈簧   |

2004.05.18


26111-GOO-00A

# DIFFERENTIAL 差速器




| NO. | PARTS NO.     | PARTS NAME              |        | Q'TY | NOTE |
|-----|---------------|-------------------------|--------|------|------|
| 項目  | 零件號碼          | 零件名稱                    |        | 用量   | 備註   |
| 1   | 26422-GOO-00  | DRIVE GEAR 65T          | 傳動齒輪   | 1    |      |
| 2   | 26611-GOT-00  | CRANKCASE, DIFFERENTIAL | 差速器箱   | 1    |      |
| 3   | 26621-GOT-00  | COVER, DIFFERENTIAL     | 差速器箱蓋  | 1    |      |
| 4   | 26630-GOO-00  | BEVEL GEAR 1            | 斜齒輪 1  | 2    |      |
| 5   | 26631-GOO-00  | SHAFT, GEAR             | 齒輪軸    | 1    |      |
| 6   | 26640-GOO-00  | BEVEL GEAR 2            | 斜齒輪 2  | 2    |      |
| 7   | 93110-20358   | OIL SEAL TC 20*35*8     | 油封     | 2    |      |
| 8   | 93320-305513M | BALL BEARING 6006CM/2A  | 滾珠軸承   | 2    |      |
| 9   | 94430-30022-K | PIN, DOWEL              | 彈簧銷    | 1    |      |
| 10  | 94706-08025-G | BOLT, SOCKET            | 六角承窩螺栓 | 8    |      |

# GENERATOR 發電機



| NO.<br>項目 | PARTS NO.<br>零件號碼 | PARTS NAME<br>零件名稱          |           | Q'TY<br>用量 | NOTE<br>備註 |
|-----------|-------------------|-----------------------------|-----------|------------|------------|
| 1         | 35500-NAF-00      | GENERATOR ASSEMBLY          | 發電機總成     | 1          |            |
| 2         | 35550-NAF-00      | ROTOR ASSEMBLY              | 轉子總成      | 1          |            |
| 3         | 35560-NAF-00      | BASE ASSEMBLY               | 發電機座總成    | 1          |            |
| 4         | 35580-NAF-00      | COIL, PULSE                 | 脈動線圈      | 1          |            |
| 5         | 93110-19265       | OIL SEAL                    | 油封        | 1          |            |
| 6         | 95201-101408-C    | NUT, HEXAGON                | 六角螺帽      | 1          |            |
| 7         | 96310-06016-C     | SCREW, PAN HEAD             | 十字孔頭螺絲    | 2          |            |
| 8         | 96312-04008-C     | SCREW, PAN HEAD WITH WASHER | 十字孔頭螺絲附墊圈 | 1          |            |
| 9         | 96312-06010-C     | SCREW, PAN HEAD WITH WASHER | 十字孔頭螺絲附墊圈 | 2          |            |
| 10        | 96312-06025-C     | SCREW, PAN HEAD WITH WASHER | 十字孔頭螺絲附墊圈 | 2          |            |
| 11        | 97201-101726-C    | WASHER, PLATE               | 平面墊圈      | 1          |            |

# STARTING MOTOR 起動馬達



| NO. | PARTS NO.     | PARTS NAME              |        | Q'TY | NOTE |
|-----|---------------|-------------------------|--------|------|------|
| 項目  | 零件號碼          | 零件名稱                    |        | 用量   | 備註   |
| 1   | 35800-NAN-00  | STARTING MOTOR ASSEMBLY | 起動馬達   | 1    |      |
| 2   | 35801-NAN-00  | BRUSH SET               | 電刷組    | 1    |      |
| 3   | 35811-NAN-00  | GASKET, YOKE            | 墊片     | 1    |      |
| 4   | 93210-19230   | O-RING                  | 護油圈    | 1    |      |
| 5   | 96414-04068-C | BOLT, FLANGE            | 凸緣螺栓   | 2    |      |
| 6   | 96510-06020-G | BOLT, SOCKET            | 六角承窩螺栓 | 2    |      |